



How To Fix Your Unibody Macbook Trackpad *A GoGeeks.tv Tutorial*


Step 1: Unscrew the 10 screws with the #00 Philips screwdriver (keep note that the 3 screws on the top-left are longer than the rest) and remove the backplate.



Step 2: Unscrew the two screws holding the battery down with the Tri-Wing Screwdriver.



Step 4: Unplug the battery and remove the battery.



Step 5: Here you should see the bottom of the trackpad, on the trackpad you'll notice a screw (circled below). All you need to do is SLIGHTLY tighten/loosen the screw (1/8th of a full rotation).



Step 6: put your computer back together (reverse above directions) and test the trackpad, you may need to open the computer back up a few times to get your trackpad working perfectly, remember to only adjust the trackpad slightly at a time, the slighthly rotation makes a huge difference.

If you have any additional questions, read the FAQ on the website, if it isn't listed there, leave a comment on that post.